

INSTALLATION INSTRUCTIONS

Troldtekt® acoustic panels and Troldtekt® Plus installed in exposed T24 profiles in removable, suspended ceiling system

These instructions apply to installation of Troldtekt® acoustic panels and Troldtekt® Plus in exposed T24 profiles in removable, exposed ceiling system. Download installation instructions for Troldtekt® T24 profile system from www.troldtekt.com.

PROFILE DRAWINGS Panel thickness 25 mm / 35 mm Panel thickness 35 mm KO-FS: With rebate for KO-S: Square edge for K5-FS: With rebate and 5 mm KO-SB: With rebate on the exposed T-profile exposed T-profile bevel for exposed T-profile back along T-profile K0-FS K0-S: K5-FS: Troldtekt akustik Plus Troldtekt akustik Plus Troldtekt akustik Plus Panel thickness 15 mm / 25 mm / 35 mm Please note: Troldtekt Plus 15 can only be used with KO-S K0-FS: K0-S: K5-FS: Troldtekt Plus 25 & 35 Troldtekt Plus 15, 25 & 35 Troldtekt Plus 25 & 35

INSTALLATION

Check that all hangers are secure after installation of the profile system. Adjust if necessary. Now lay the Troldtekt panels in the grid.

Note: When installing **600 × 600 mm** square panels, it is important to ensure that the wood wool fibres run mainly parallel in one direction.

You can ensure that the panels face the same way by looking at the printed text on the back of the panels. This text must always face the same way.

WWW.TROLDTEKT.COM MAY 2025 EN V01 PAGE 1/2



ILLUSTRATION - INSTALLATION



